




# EDR 100



<b>IT</b>	ISTRUZIONI DI MONTAGGIO
<b>FR</b>	INSTRUCTIONS DE MONTAGE
<b>EN</b>	MOUNTING INSTRUCTIONS
<b>DE</b>	MONTAGEANLEITUNG
<b>NL</b>	MONTAGEVOORSCHRIFT
<b>ES</b>	GUÍA DE MONTAJE
<b>PT</b>	INSTRUÇÕES DE MONTAGEM
<b>EL</b>	ΟΔΗΓΙΕΣ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
<b>RU</b>	ИНСТРУКЦИИ ПО УСТАНОВКЕ
<b>PL</b>	INSTRUKCJA MONTAŻU
<b>CZ</b>	NÁVOD K MONTÁŽI
<b>RO</b>	INSTRUCTIUNI DE MONTARE
<b>HU</b>	SZERELÉSI ÚTMUTATÓ
<b>SE</b>	MONTERINGSANVISNINGAR
<b>NO</b>	MONTERINGSINSTRUKSJONER
<b>FI</b>	ASENNUSOHJEET

Ref.	Cod.
1	L7560116
2	L7605005
3	L3083013
4	L7628079
5	L7560232
6	L7097222
8	L7560096
9	L7097176



**IT** Dado autobloccante, specifico per evitare svitamenti accidentali. Avvitare in maniera decisa, con gli appositi attrezzi, anche dopo aver aperto la scatola.

**FR** Écrou autobloquant, conçu pour éviter tout desserrage accidentel. Serrez fermement, avec les outils appropriés, même après avoir ouvert la boîte.

**EN** Self-locking nut, designed to prevent accidental loosening. Tighten firmly, with the correct tools, even after opening the box.

**ES** Tuerca autobloqueante para evitar que se afloje. Enroscar a fondo con las herramientas específicas, incluso después de haber abierto la caja.

