


IT ASCIUGATRICE
FR SÈCHE-LINGE
EN DRYER
ES SECADORA
CZ SUŠIČKA
PL SUSZARKA
DE TROCKNERMax
70 cm
60 cmTORRE
DRYIT LAVATRICE
FR LAVE-LINGE
EN WASHING MACHINE
ES LAVADORA
CZ PRAČKA
PL PRALKA
DE WASCHMASCHINEMin
45 cm
60 cmTORRE
DRYIT DIMENSIONE PRODOTTO
FR DIMENSIONS DU PRODUIT
EN PRODUCT DIMENSIONS
ES DIMENSIONES DEL PRODUCTO
CZ ROZMĚRY PRODUKTU
PL WYMIARY PRODUKTU
DE PRODUKTGRÖSSE1
IT Estrarre e rimuovere il ripiano
FR Faites coulisser la tablette et retirez-la
EN Slide the shelf out and remove it
ES Extraiga y desmonte la bandeja
CZ Vyměňte polici
PL Wyjąć i wyjąć półkę
DE Ablage ausziehen und entnehmen